

DIGITAL ELECTRONIC SAFE



Please read all of these instructions carefully before commencing using your safe. Try all of these procedures with the door open first, until you are familiar with how the safe works.

FEATURES

- High performance microprocessor.
- Possible combinations: 10 billion.
- Internal power supply with **alkaline battery(es)** (read inside the batteries case the size of battery of your safe PIC.1).
- Alphanumeric keyboard with 12 keys: 10 keys with numbers from 0 to 9 and 26 letters.
- “ON” key to activate the circuit.
- “ENTER” key to confirm code set.
- The keyboard is of the membrane type with four dedicated LEDs, and contacts for external emergency power supply in the event of internal batteries being flat.
- Internal button for programming new personal code.
- **DIGITS THAT CAN BE SET** minimum 4 – maximum 10 digits in permanent memory (the “ENTER” and “ON” keys are not valid in the combination).

INTRODUCTION

- **ALL SAFES ARE PROVIDED WITH SERVICE CODE “1111”.**
- Before installing the safe, check that it works properly and read the instructions carefully to understand the operation.
- Every time a key is pressed the green “OK” LED lights up and the buzzer sounds; pressing the “ENTER” key causes the green “OK” LED to light up for correct procedures, or the red “ERROR” LED to light up in the case of incorrect settings.

INSTRUCTIONS FOR USE

1. Fit the **battery(es) - only alkaline batteries must be used** - in its plastic seating on the back of the internal lock (see **Pic. 1**) in the **indicated size** and completely remove (**without screwing it back in**) the screw marked with a special yellow label, which blocks the magnet.
2. **Test for opening using the service code “1111” (with door open and bolts extended)**
 - Press “ON”, key in the service code “1111” and press “ENTER”. The green “OK” LED lights up for about five seconds.
 - Within this time, with the green LED “ON”, turn the knob clockwise to retract the bolts.
 - If the combination is incorrect, the red “ERROR” LED will light up and the buzzer will sound.
 - After three attempts with incorrect codes, the keyboard will be disabled for one minute and this time will be indicated by the red “ERROR” LED flashing. After this time, renewed readiness for operation will be indicated by the green “OK” LED lighting up and a beep.

STORING THE PERSONAL CODE

3. **The procedure for storing the new code must be carried out with the door open and the bolts extended.**
 - Press “ON”.
 - Press the programming button near the top of the back of the door once; the button is marked with a yellow “PROGRAMMING” label (**Pic.1**).The green “CODE” LED switches on with a steady light and stays on for 10 seconds.
 - Within 10 seconds, start keying in your new personal code (**min. 4 – max. 10 digits**) and press “ENTER” Key in your new code set again and press “ENTER” to confirm.If the procedure has been carried out correctly, a long sound with a number of tones is emitted, thus indicating that your code has been stored.
If errors have been made while setting your new code, this will be indicated by the red “ERROR” LED lighting up and a beep. Repeat the procedure for setting your new personal code again, starting from 3.

Before finally closing the safe, it is advisable to check that everything is OK by operating the opening and closing mechanism a number of times with the door open. Then shut the door and turn the knob anticlockwise until it is closed

OPENING THE SAFE USING YOUR PERSONAL CODE

- Press “ON”
- Enter your personal code set earlier and press “ENTER”. The green “OK” LED lights up for five seconds. Within this time, turn the knob clockwise and open the door

SIGNAL INDICATING THAT INTERNAL BATTERY(ES) ARE GOING FLAT

When the internal battery begins to go flat, this is indicated at the end of the opening procedure, by the red “BATTERY” LED lighting up and a low beep tone. At this point, it will still be possible to open the safe a number of times. Replace the internal batteries.

EMERGENCY OPENING WITH INTERNAL BATTERY(ES) FLAT

If the failing battery(es) goes completely flat, as soon as the keyboard is pressed, to proceed with opening the safe, it is necessary to use a **new 9-volt LR61 alkaline battery** externally (see **Pic. 2**)

Press the **9-volt battery** contacts firmly on the corresponding contacts on the keyboards, ensuring that they are positioned correctly (the “-“ of the battery touching the bigger contact and the “+” of the battery touching the small contact). With the battery firmly in position, key in code and open door. Replace internal batteries immediately.

CAUTION

Wall safes: After installing the safe in the wall, leave the safe open for a few days allow any dampness to dry out.

Replace alkaline batteries every year.

It must be remembered that even new, packed batteries can sometimes be defective, for various reasons, or have a brief duration. In the event of failure of the magnet release, or other faults, first of all, replace the battery with a new alkaline batteries.

The manufacture declines all responsibility for failure to observe the instructions given, or for improper use of the safe, thus causing the warranty to lapse.

Versions with EMERGENCY KEY

OPENING WITH EMERGENCY KEY

- Remove the adhesive label marked with the letter “E” (**Pic.3**).
- Insert the key and open the lock up to the stop point.
- Open the door.
- Once the door is open, turn the knob anticlockwise until the bolts are fully extended.
- Close the lock and remove the key.

WARNING!
NEVER LEAVE YOUR
EMERGENCY KEY IN THE
SAFE

